

SURFACE PREPARATION FOR WALL MURALS

The preparation of a wall is the most vital part of the installation process. If the wall is not properly prepared the graphic will fail. These instructions must be followed to the letter. Any variation may cause additional expenses.

WALL PREPARATION:

1. All drywall dust must be removed prior to painting the wall.
2. Wipe the area where the graphics is to be installed.
3. The wall must be painted with primer all the way to the perimeter edges.
4. Check the wall for any imperfections. Any imperfection will be magnified 2 or 3 times when the graphic is installed.
5. The wall must be painted with no less than a semi-gloss finish.
6. The paint must dry/cure for a minimum of 72 hours. Oil base is two times the drying time on the can label.
7. The entire area of the wall that is to have graphics applied is to be painted.
8. Vinyl graphics will not adhere well to dry wall, drywall mud or primer, also paints that have a finish of flat or eggshell.
9. PLEASE NOTE FOR NEW CONSTRUCTION ON OUR QUOTE / ESTIMATES: Changes in sizing and conditions of actual construction will change scope and most likely our pricing.

I understand the contents of this page and that if these procedures are not followed, the quality of my wall mural may be compromised and not at the liability of Cushing or the installers. I also understand that the installer may refuse application of my mural at the time of installation if these procedures are not followed.

X _____

